

Technical Data Sheet

Page 1 of 1

Properties:	Dosing dispenser for wall mounting for common 2.3 kg and 3.0 kg body filler cartridges. - clean and uniform mixing - the perfect ratio of putty dimensions and hardener - no contamination or drying out
Application Area:	Allows for the precise measuring of polyester putty and hardener in order to ensure the correct mixing ratio.
Instructions for Use:	1. Push back the body filler and hardener squeezers. 2. Put the opened body filler cartridge into the dispenser. 3. Put the opened harder stick into the dispenser. 4. Move the lever down for extrude body filler and hardener.
Special Notes:	- The dispenser should operate in the vertical position. - It is recommended to fix the extruder, e.g. to the wall, using the supplied expansion bolts and spacer sleeves.
Technical Data:	Dimension: 800 x 160 x 125 (H x W x D)
Storage:	Not applicable.
Health & Safety:	Not applicable.
Important Notice:	The above information is based on the latest stage of development and application technology. Due to a multiplicity of different influencing factors, this information – as well as other oral or written technical advises – must be considered as non-binding hints. The user is obliged in each particular case to conduct performance tests, including but not limited to trails of the product, in an inconspicuous area or fabrication of a sample piece.

TDS 05.21